

OUC Customer Connection

OUC Backflow Prevention Requirements

ABBREVIATIONS: RPDA – Reduced Pressure Detector Assembly
RPZ – Reduced Pressure Zone
DCVA – Double Check Valve Assembly

***Note: RPDA are to be used on non-metered fire services.**

Residential (Potable Water Systems)

RPDA	Fire Sprinkler System with chemical additives or any other hazardous materials
RPZ	Any irrigation system equipped with chemical injection
DCVA	Any irrigation system without chemical injection used in areas with reclaimed water available

All Others

RPDA	All non-metered fire services
RPZ	All other services

Note: For 6" devices or larger, please email backflowtesting@ouc.com to schedule a meeting.

***Questions or Comments
Contact OUC Backflow Department at
backflowtesting@ouc.com***